STi Mobile
Nationwide Wireless Service

LG® 1200
User Guide

LG® 1200 User Guide – Table of Contents

Welcome to STi Mobile **1**
Introduction to this User Guide **1**
Section 1 Getting Started **1**
Setting Up Service 1
Getting Started With STi Mobile 1
Determine If Your Phone Is Already Activated 1
Unlocking Your Phone 1
Activating Your Phone 1
Setting Up Your Voicemail 1
Getting Help 1
Visit Our Web Site 1
Reaching STi Mobile Customer Care 2
Section 2 Understanding Your STi Mobile Phone **2**
Section 2A Your STi Mobile Phone: The Basics **2**
Front View of Phone 2
Key Functions 2
Viewing the Display Screen 2
Features of Your STi Mobile LG® 1200 3
Turning Your Phone ON and OFF 3
Turning Your Phone ON 3
Using the Battery 3
Battery Capacity 3
Installing the Battery 3
Removing the Battery 3
Charging the Battery 4
Using the AC Adapter Charger 4
Displaying Your Phone Number 4
Making and Answering Calls 4
Missed Call Notification 5
Calling Emergency Numbers 5
Dialing Options 5
In-Call Options 5
End-of-Call Options 5
Saving a Phone Number 6
Finding a Phone Number 6
Dialing and Saving Phone Numbers With Pauses 6
Four-Digit Calling 6
Dialing From the Internal Phone Book 6
Using One-Touch/Two-Touch Speed Dialing 7
Entering Text 7
Selecting a Character Input Mode 7
Entering Characters Using T9 Text Input 7
Adding a Word to the T9 Database 7
Entering Characters by Tapping the Keypad 7
Entering Symbols and Numbers 8
Section 2B **8**
Controlling Your Phone's Settings **8**
Sound Settings 8
Adjusting the Phone's Volume Settings 8

Selecting a Key Tone Length 8
Ringer Types 8
Selecting Ringer Types for Voice Calls 8
Selecting Ringer Types for Messages 9
Alert Notification 9
Silent Mode 9
Display Settings 9
Changing the Backlight Time Length 9
Changing the Greeting 9
Changing the Contrast 10
Changing the Power On/Off and Screen Saver Display Options 10
Power On/Off 10
Screen Saver 10
Changing the Display Language 10
Location Settings 10
Phone Setup Options 11
Call Answer Mode 11
Auto-Answer Mode 11
Section 2C 11
Setting Your Phone's Security 11
Accessing the Security Menu 11
Locking Your Phone 11
Unlocking Your Phone 12
Changing the Lock Code 12
Calling in Lock Mode 12
Using Special Numbers 12
Erasing the Internal Phone Book 12
Resetting Your Phone 12
Section 2D: Understanding Your STi Mobile Phone 12
Navigating Through Menus 12
Menu Navigation 13
Menu Structure 13
Selecting Menu Items 13
Backing Up Within a Menu 13
Viewing the Menus 13
Section 2F 14
Managing Call History 14
Viewing Call History 15
Call History Options 15
Making a Call From Call History 15
Saving a Phone Number From Call History 15
Prepending a Phone Number From 16
Call History 16
Erasing Call History 16
Section 2G 16
Using the Internal Phone Book 16
Displaying an Internal Phone Book Entry 16
Finding Names 16
Finding Numbers 17
Finding Speed Dial Numbers 17
Internal Phone Book Entry Options 17
Adding a New Internal Phone Book Entry 17
Adding a Phone Number to an Internal Phone 17

Book Entry 17
Editing an Internal Phone Book Entry's 18
Phone Number 18
Editing an Internal Phone Book Entry 18
Selecting a Ringer Type for an Entry 18
Secret Internal Phone Book Entries 18
Managing Speed Dial Settings 19
Using the Scheduler, Calculator, and Games 19
Using the Scheduler 19
Adding an Event to the Scheduler 19
Event Alerts 20
Event Alert Menu 20
Viewing Events and Event Options 20
Editing an Event's Title 20
Editing an Event's Settings 20
Editing an Event's Ringer Type 20
Editing an Event's Alarm 20
Editing an Event's Repeating Status 21
Erasing a Day's Events 21
Going to Today's Scheduler Menu 21
Displaying the Week or Month View 21
Purging Events 21
Purging All Events 22
Viewing Scheduler Memory Space 22
Viewing Scheduler Help 22
Using the Calculator 22
Playing Games 22
Adjusting Games Settings 22
Section 3 23
Using STi Mobile 23
Service Features 23
Section 3A 23
STi Mobile Service Features: 23
The Basics 23
Messaging Basics 23
Knowing When You Have Messages 23
Message Types 23
Using Voicemail 23
Setting Up Your Voicemail 23
Voicemail Notification 23
New Voicemail Message Alerts 24
Retrieving Your Voicemail Messages 24
Using One-Touch Message Access: 24
Using a Phone Other Than Your STi Mobile Phone to Access Messages: 24
Voicemail Button Guide 24
Voicemail Options 24
Using Expert Mode 24
STi Mobile Callback 24
Voicemail-to-Voicemail Message 25
Voicemail-to-Voicemail Message Reply 25
Voicemail-to-Voicemail Receipt Request 25
Continue Recording 25
Clearing the Message Icon 25

Voicemail Menu Key 25
STi Mobile Messages 26
Message Notification 26
Receiving New Messages 26
Viewing Saved Messages 26
Storing Messages 26
Message Options 26
Extracting Phone Numbers From a Message 26
Prepending a Phone Number From a Message 27
Creating Folders for Messages 27
Editing Message Folders 27
Erasing All STi Mobile Messages 27
Using Caller ID 28
Section 4 28
Safety Guidelines and 28
Warranty Information 28
Section 4A 28
Safety 28
Getting the Most Out of Your Reception 28
Keeping Tabs on Signal Strength 28
Understanding the Power Save Feature 28
Understanding How Your Phone Operates 28
Knowing Radiofrequency Safety 28
Maintaining Your Phone's Peak Performance 28
Maintaining Safe Use of and Access to 29
Your Phone 29
Using Your Phone While Driving 29
Following Safety Guidelines 29
Using Your Phone Near Other Electronic Devices 29
Turning Off Your Phone Before Flying 29
Turning Off Your Phone in Dangerous Areas 29
Restricting Children's Access to your Phone 30
Caring for the Battery 30
Protecting Your Battery 30
Disposal of Lithium Ion (LiIon) Batteries 30
Acknowledging Special Precautions and the 30
FCC Notice 30
FCC Notice 30
Cautions 30
Body-Worn Operation 30
Specific Absorption Rates (SAR) for Wireless Phones 30
FCC Radiofrequency Emission 31
Owner's Record 31
User Guide Proprietary Notice 31
Section 4B 31
Manufacturer's Warranty 31
In This Section ..... Error! Bookmark not defined.
_ Manufacturer's Warranty 31
Customer Limited Warranty 31
Index 32

Welcome to STi Mobile

STi Mobile uses an all-digital network with advanced multimedia services, reaching more than 240 million people. With STi Mobile, you can do something even more far-reaching – simplify your life. The advanced technology we use is designed to grow with your communications needs so that one day you'll be able to rely entirely on your STi Mobile phone to stay connected. This guide will familiarize you with our service and your new STi Mobile phone through simple, easy-to-follow instructions. If you have already reviewed the User tips foldout, which was packaged with your new phone, then you're ready to explore the advanced features outlined in this guide. If you have not read your User tips foldout, go to Getting Started. This section provides all the information you need to quickly activate your phone, set up your voicemail, and much more. It also contains information on how to contact STi Mobile should you have questions about service, wish to check your account balance, or want to purchase additional products or services. Thank you for choosing STi Mobile.

Introduction to this User Guide

This User Guide introduces you to STi Mobile's service and all the features of your new phone. It's divided into four sections:

- **Section 1:** Getting Started
- **Section 2:** Understanding Your Phone
- **Section 3:** Using STi Mobile Service Features
- **Section 4:** Safety and Warranty Information

Throughout the guide, you'll find tips that highlight special shortcuts and timely reminders to help you make the most of your new phone and service. The Table of Contents and Index will help you locate specific information quickly. You'll get the most out of your phone if you read each section. However, if you'd like to get right to a specific feature, simply turn to that page. Follow the instructions in that section and you'll be ready to use your phone in no time.

Section 1 Getting Started

Setting Up Service

In This Section

- **Getting Started With STi Mobile Service**
- **Setting Up Voicemail**
- **Getting Help**

This section walks you through setting up service for your STi Mobile phone, unlocking your phone, setting up your voicemail, and how to contact STi Mobile Customer Care for assistance.

Getting Started With STi Mobile

Determine If Your Phone Is Already Activated

If you received your phone in the mail or purchased it at a retail store, your phone may already be activated. All you need to do is unlock your phone. If your phone is not activated, please refer to the User tips foldout included with your phone.

Unlocking Your Phone

Follow these steps to unlock your phone:

1. Press and hold **END/PWR** to turn the phone on.
2. Highlight **Unlock** and press **OK**.
3. Enter your four-digit lock code. For security purposes, the code is not visible as you type.

Tip: If you can't recall your lock code, try using the last four digits of either your Social Security number or STi Mobile phone Number or try 0000. If none of these work, call STi Mobile Customer Care at 1-800-784-3277.

Activating Your Phone

To activate your phone, follow the directions in the User tips foldout included with your phone.

Setting Up Your Voicemail

All unanswered calls to your STi Mobile phone are automatically transferred to voicemail, even if your phone is in use or turned off. Therefore, you will want to set up your voicemail and personal greeting as soon as your STi Mobile phone is activated.

To set up voicemail:

1. Press and hold the navigation button.
2. Highlight **Voicemail** and press **OK**.
3. Highlight **Call** and press **OK**.
4. Follow the system prompts to create your pass code, record your greeting, record your name announcement, and choose whether to activate One-Touch Message Access (a feature that lets you access messages simply by pressing and holding **1**, bypassing the need for you to enter your pass code).

Note: The voicemail setup process may vary in certain Affiliate areas. For more information about using your voicemail, see "Using Voicemail" on page 79.

Getting Help

Visit Our Web Site

Go to www.stimobile.com for more information on STi Mobile services and options.
You can also:

- View coverage maps
- Learn how to use voicemail
- Purchase Recharge Cards and accessories
- Get answers to frequently asked questions

Reaching STi Mobile Customer Care
You can reach STi Mobile Customer Care by:
- Dialing ✳611 on your STi Mobile phone
- Calling us toll-free at 1-800-784-3277 (Consumer customers); or
- Writing to us at STi Mobile, 30-50 Whitestone Expressway, Flushing, NY 11354.

Section 2 Understanding Your STi Mobile Phone

Section 2A Your STi Mobile Phone: The Basics

In This Section

_**Front View of Phone**
_**Key Functions**
_**Features of Your Phone**
_**Turning Your Phone On and Off**
_**Using the Battery and Charger**
_**Displaying Your Phone Number**
_**Making and Answering Calls**

Your STi Mobile phone is packed with features that simplify your life and expand your ability to stay connected to the people and information that are important to you. This section will guide you through the basic functions and calling features of your phone.

Front View of Phone

1. Display Screen
2. Headset Jack
3. Volume Button
4. OK Button
5. AC Adapter Jack
6. Power On Indicator/LED
7. Navigation Key
8. End Button (Power)
9. Back Button (Clear)
10. Microphone

Key Functions

1. Display Screen: Displays phone status icons and menu items.
2. Headset Jack: Provides connection for an optional headset.
3. Volume Button: Adjust the ringer volume during standby mode or voice volume during a call.
4. OK Button: Lets you place or answer a call, select highlighted menu items, and confirm actions.
5. AC Adapter Jack: Provides connection for the AC adapter charger.
6. Power On Indicator/LED: Flashes when phone is powering up. Also flashes to alert you of incoming calls, messages, and scheduler alarms.
7. Navigation Key: Scrolls through menus and displays the next or previous menu option. Also acts as a shortcut key for your internal phone book (left) and voicemail box (right).
8. End Button (Power): Lets you power the phone on or off, end calls, or return to standby mode from any screen.
9. Back Button (Clear): Lets you clear an entry or back up within a menu.
10. Microphone: May be muted for privacy during a call.

Viewing the Display Screen

This list identifies the symbols you'll see on your display screen.
_shows your current signal strength. The more lines you have, the stronger your signal.
_means your phone cannot find a signal.
_tells you a call is in progress.
_indicates you are "roaming" off the enhanced STi Mobile Coverage Area.

_indicates your phone is in vibrate mode.
_indicates you have new text messages.
_indicates you have voicemail messages. Press and hold to call your voicemail box.
_indicates you have new text and voice messages.
_indicates your phone's location feature is enabled. When Location is "Off," appears on the display screen.
_shows your current battery charge strength.
(Icon is shown fully charged.)

Tip: Display indicators let you know when you're off the enhanced STi Mobile Coverage Area.

Features of Your STi Mobile LG® 1200

Congratulations on the purchase of your STi Mobile LG® 1200. This phone is lightweight, easy-to-use, and reliable. It also offers many significant features and service options:
_The built-in scheduler can be used to schedule alerts to remind you of important events (page 65).
_One hundred ninety-nine internal phone book entries store up to five phone numbers each (page 57).
_T9® Text input lets you quickly enter text by using one key press per letter (page 26).
_Speed dialing lets you dial phone numbers by pressing one or two digits (page 25).
_Built-in games offer an entertaining diversion (page 73).
_More than a dozen preprogrammed ringers let you personalize your phone (page 31).

Turning Your Phone ON and OFF

Turning Your Phone ON

To turn your phone on, press **END/PWR** for approximately two seconds.
Once your phone is ON, it displays "Searching for Service" which indicates that your phone is searching for a signal. When your phone finds a signal, it automatically enters standby mode – the phone's idle state. At this point, you are ready to begin making and receiving calls.
If your phone is unable to find a signal after 15 minutes of searching, a Power Save feature is automatically activated. When a signal is found, your phone automatically returns to standby mode.
In Power Save mode, your phone searches for a signal periodically without your intervention. You can also initiate a search for STi Mobile service by pressing any key (when your phone is turned ON).

Tip: The Power Save feature helps to conserve your battery power when you are in an area where there is no signal.

Turning Your Phone OFF

Press and hold **END/PWR** until you see the powering down message and animation (for example, "LG Goodbye!") on the display screen. Your screen remains blank while your phone is off (unless the battery is charging).

Using the Battery

Battery Capacity

Your STi Mobile phone is equipped with a Lithium Ion (LiIon) battery. It allows you to recharge your battery before it is fully drained. The battery provides approximately 2.5 hours of continuous digital talk time or approximately **[48]** hours of continuous digital standby time. When there are approximately two minutes of talk time left, the phone sounds an audible alert and then powers down.

Note: Long backlight settings, searching for service, vibrate mode and browser use affect the battery's talk and standby times.

Tip: Be sure to watch your phone's battery level indicator and charge the battery before it runs out of power.

Installing the Battery

Your STi Mobile phone comes with a LiIon battery. Follow these steps to install it:
1. Place the battery in the opening at the back of the phone at a 45-degree angle with the metal contacts at the bottom, facing downward.
2. Gently press down on the battery until the latch snaps into place.

Removing the Battery

To remove your battery, follow these easy steps:
1. Make sure the power is off so that you don't lose any stored numbers or messages.

2. Push up on the battery release latch on the back of the phone.
3. Remove the battery from the phone at a 45-degree angle.

Charging the Battery

Your STi Mobile phone comes with a rechargeable battery. You should charge the battery as soon as possible so you can begin using your phone.
Keeping track of your battery's charge is important. If your battery level becomes too low, your phone automatically turns off and you will lose any unsaved data. For a quick check of your phone's battery level, glance at the battery charge indicator located in the upper-right corner of your phone's display screen. If the battery charge is getting too low, the battery icon blinks and the phone sounds a warning tone.
Always use a STi-approved AC adapter charger or vehicle power adapter to charge your battery.
Warning! Using the wrong battery charger could cause damage to your phone and void the warranty.

Using the AC Adapter Charger

To use the AC adapter charger provided with your phone:
1. Plug the AC adapter into an electrical outlet.
2. Insert the round end of the adapter into the AC adapter jack at the bottom of the phone. (Make sure the battery is installed.)
_A beep lets you know the adapter is attached to the phone.
_As the phone charges, the battery icon continually displays a progression from empty to full. When charging is complete, the battery full icon will blink.
It takes approximately two hours to fully recharge a completely rundown battery. With the STi Mobile approved LiIon battery, you can recharge the battery before it becomes completely run down.

Displaying Your Phone Number

Just in case you forget your phone number, your STi Mobile phone can remind you.
To display your phone number:
1. Highlight **Phone Book** and press the **OK** button.
2. Highlight **My Phone #** and press **OK**.
You can also display your phone number by highlighting **Phone Info** and pressing **OK**.

Making and Answering Calls

Making Calls

Your STi Mobile phone offers many different ways to make calls, including Speed Dialing (page 25) and using Call History (page 53).
To make a call using your keypad:
1. Make sure your phone is on.
2. Enter a phone number. (If you make a mistake while dialing, press **BACK** to erase one digit at a time. Press and hold **BACK** to erase the entire number.)
3. Press **OK.**
4. When you're finished, press **END** or close the phone.
Tip: To redial your last outgoing call, press and hold **OK**.

Answering Calls

1. Make sure your phone is on. If your phone is off, incoming calls go to voicemail.
2. When a call comes in, answer the call by opening the phone or by highlighting **Answer** and **OK**. Depending on your settings, your STi Mobile phone notifies you of incoming calls in the following ways:
_The phone rings or vibrates.
_The LED flashes.
_The backlight illuminates.
_The screen displays an incoming call message.
_If available, the phone number of the caller is displayed.
_If the phone number is in your Internal Phone Book, the Phone Book entry's name is displayed.
The following options are also displayed. To select an option, highlight it and press **OK**.
_**Silence Ringer** to mute the ringer.
_**Ignore** to send the call to your voicemail box.
Depending on your settings, you may also answer incoming calls by pressing any digit **Note:** If your phone is off, incoming calls go to voicemail.
3. To disconnect the call, close the phone or press **END/PWR**.

Missed Call Notification

When an incoming call is not answered, the Missed Call log is displayed on your screen.
To display the Missed Call entry:
_Highlight the entry and press **OK**. (To dial the phone number, highlight **Call** and press **OK**.)

Calling Emergency Numbers

Your can place calls to 911 (dial **911** and press **OK**), even if your phone is locked or your account is restricted.

Dialing Options

Dialing options are displayed when you enter numbers in the phone's standby mode.
To initiate an action, highlight it and press **OK**.
_**Call** to dial the phone number.
_**Save** to save the phone number in your Internal Phone Book.
(See "Saving a Phone Number" on page 22.)
_**Find** to display Internal Phone Book entries that contain the entered numbers. (See "Finding a Phone Number" on page 23.)
_**[An Internal Phone Book Entry]** to display the listing contained in the speed dial location you entered (if applicable). Highlight **Call** and press **OK** to dial the speed dial number.
Tip: To speed dial a phone number from standby mode, press and hold the speed dial number. If the speed dial number is two digits, enter the first digit, then press and hold the second digit. (For information on assigning speed dial numbers, see "Editing an Internal Phone Book Entry's Phone Number" on page 62.)
_**Hard Pause** to insert a hard pause. (See "Dialing and Saving Phone Numbers With Pauses" on page 23.)
_**2-Second Pause** to insert a 2-second pause. (See "Dialing and Saving Phone Numbers With Pauses" on page 23.)
_**4-Digit Call** to dial the phone number in your Internal Phone Book that ends with the four digits you enter. (See "4-Digit Calling" on page 24.)
_**Exit** to return to the main menu.

In-Call Options

During a call, your phone displays menu options in addition to the main menu.
To select an option, highlight it and press **OK**.
_**Flash** to answer an incoming call using Call Waiting or connect a third party during Three-Way Calling (if applicable). (See "Responding to Call Waiting" on page 91.)
_**End Call** to end the call.
_**Mute** or **Unmute**
Select **Mute** to mute your phone's microphone. Select **Unmute** to reactivate the microphone.
_**Call History** to display the Call History menu.
(See "Managing Call History" on page 51.)
_**Messages** to display the Messages menu.
(See "Messaging Basics" on page 78.)
_**Phone Book** to display the Internal Phone Book menu.
(See "Using the Internal Phone Book" on page 57.)
_**Display** to change your phone's display settings.
(See "Display Settings" on page 33.)
_**Phone Info.** to display your phone's information screen.
_**Calculator** to display your phone's calculator.
(See "Using the Calculator" on page 72.)

End-of-Call Options

After receiving a call from or making a call to a phone number that is not in your Internal Phone Book, the phone number, the duration of the call and the following menu options are displayed.
To select an option, highlight it and press **OK**.
_**OK** to return to the main menu. (You can also press **End**.)
_**Call** to dial the phone number.
_**Save** to save the phone number in your Internal Phone Book. (See "Saving a Phone Number" on page 22.)

After receiving a call from or making a call to a phone number that is already in your Internal Phone Book, the Phone Book entry name and phone number, the duration of the call, and the following menu options are displayed.
To select an option, highlight it and press **OK**.

_**OK** to return to the main menu. (You can also press **End**.)
_**Call** to dial the phone number.
Note: The End-of-Call options are not displayed for calls identified as No ID or Restricted.

Saving a Phone Number

Your STi Mobile phone can store up to five phone numbers in each of 99 Internal Phone Book entries. Each entry's name can contain 16 characters. Your phone automatically sorts the Internal Phone Book entries alphabetically.
To save a number from standby mode:
1. Enter a phone number.
2. Highlight **Save** and press **OK**.
3. Highlight a label and press **OK**.
Note: A phone number labeled Fax can only be dialed through a personal computer.
4. Enter a name for the entry or select an existing entry and press **OK**. (See "Entering Text" on page 25.)
5. To select an option, highlight it and press **OK**.
_**Done** to save the entry.
_**Set Speed Dial** to assign a speed dial location for the number. Highlight or enter the desired speed dial number and press **OK**. (See "Using One-Touch/Two-Touch Speed Dialing" on page 25.)
After saving the number, the number's Internal Phone Book entry is displayed. (See "Internal Phone Book Entry Options" on page 59.)

Finding a Phone Number

You can search Internal Phone Book entries for phone numbers that contain a specific string of numbers.
To find a phone number:
1. Enter one or more digits. The more numbers you enter, the more specific the search becomes.
2. Highlight **Search** and press **OK**.
3. To display the Internal Phone Book entry that contains the phone number, highlight the entry and press **OK**. To dial the number, press again.

Dialing and Saving Phone Numbers With Pauses

You can dial or save phone numbers with pauses for use with automated systems, such as voicemail or credit card billing numbers. If you select a hard pause, the next set of numbers are sent when you highlight **Send Tones** and press **OK**. If you select a 2-second pause, your phone automatically sends the next set of numbers after two seconds.
Note: You can have multiple pauses in a phone number and combine 2-second and hard pauses.
To dial or save phone numbers with pauses:
1. Enter the phone number.
2. Highlight either **Hard Pause** or **2-Second Pause** and press **OK**. Hard pauses are displayed as a "P" and 2-second pauses as a "T".
3. Enter additional numbers.
4. Highlight **Call** to dial the number or **Save** to save the number in your Internal Phone Book and press **OK**.
When dialing a number with a hard pause, highlight **Send Tones** and press to send the next set of numbers.

Four-Digit Calling

Enter four digits from standby mode to display the 4-Digit Calling option. If you select **4-Digit Call** your phone displays the entry in your Internal Phone Book that contains the four digits you entered.
To use 4-Digit Calling:
1. Dial the last four digits of an Internal Phone Book entry's phone number.
2. Highlight **4-Digit Call** and press **OK**.
3. The matching Internal Phone Book entry/entries will display.
Highlight the correct entry and press **OK**.

Dialing From the Internal Phone Book

To dial directly from an Internal Phone Book entry:
1. Highlight **Phone Book** and press **OK**.
2. Highlight **Find Name** and press **OK**.
Shortcut: Press the navigation key left to list entries.
3. Scroll or enter the first letters of the entry's name to highlight the entry you want to call and press to display the Internal Phone Book entry.
4. Press to dial the entry's default number. To dial another number from the entry, highlight it and press twice.

Using One-Touch/Two-Touch Speed Dialing

With this feature, you can dial Speed Dial entries using one key press for locations 1-9 or two key presses for locations 10-99.
To use **One-Touch Dialing** for Speed Dial locations 1-9:
_Press and hold the appropriate key for approximately two seconds. The display confirms that the number has been dialed when it shows “Calling...”.
To use **Two-Touch Dialing** for Speed Dial locations 10-99:
1. Press the first digit.
2. Press and hold the second digit for approximately two seconds. The display confirms that the number has been dialed when it shows “Calling...”.
Note: Speed dialing is not available when you are roaming with Call Guard enabled.

Entering Text

Selecting a Character Input Mode

Your STi Mobile phone provides convenient ways to enter words, letters, punctuation, and numbers whenever you are prompted to enter text (for example, when adding an Internal Phone Book entry).
To change the character input mode:
1. When you display a screen where you can enter text, enter one character, highlight **Mode** and press **OK**.
2. To select a character input mode, highlight it and press **OK**.
_**T9Word** to enter characters using T9 Text Input (see page 26).
_**Abc** to enter characters by tapping the keypad (see page 27).
_**SYM** to enter symbols (see page 27).
_**123** to enter numbers (see page 27).

Entering Characters Using T9 Text Input

T9 Text Input lets you enter text in your STi Mobile phone by pressing keys just once per letter. (To select the T9 Word mode when entering text, see "Selecting a Character Input Mode" on page 25.) T9 Text Input analyzes the letters you enter using an intuitive word database and creates a suitable word. (The word may change as you type.) If the word you want does not display after you have entered all the letters, press to scroll through additional word selections. To accept a word and insert a space, press **OK**.
If you make a mistake, press **BACK** to erase a single character.
Press and hold **BACK** to delete an entire entry.

Adding a Word to the T9 Database

If a word you want to enter does not display as an option when you are using T9 Text Input, you can add it to the database.
To add a word to the T9 Text Input database:
1. Select the **Abc** character input mode. (See “Selecting a Character Input Mode” on page 25.)
2. Enter the word using multi-tap text entry. (See “Entering Characters by Tapping the Keypad” on page 27.) The word will appear as an option the next time you scroll through options during T9 Text Input.

Entering Characters by Tapping the Keypad

To enter characters by tapping the keypad, select the **Abc** mode (see “Selecting a Character Input Mode” on page 25). Press the corresponding key until the desired character appears. By default, the first letter of an entry is capitalized and following letters are lowercase.
Characters scroll in the following order:
_. , - ? ! ’ @ :
_A B C 2
_D E F 3
_G H I 4
_J K L 5
_M N O 6
_P Q R S 7
_T U V 8

_W X Y Z 9
_0
_Space
_Shift
After a character is entered, the cursor automatically advances to the next space after two seconds or when you enter a character not on the same key.

Entering Symbols and Numbers

To enter symbols, select **SYM** mode. (See "Selecting a Character Input Mode" on page 25.) To enter a symbol, press the appropriate key indicated on the display. To enter numbers, select the **123** mode and press the corresponding number key. (See "Selecting a Character Input Mode" on page 25).

Section 2B Controlling Your Phone's Settings

In This Section

_**Sound Settings**
_**Display Settings**
_**Location Settings**
_**Phone Setup Options**

This section describes how you can change your phone's settings to best suit your needs. Take a few moments to review these options and add or adjust the settings that are right for you.

Sound Settings

Adjusting Volume Settings

To adjust the ringer, earpiece, key beep, or power on/off volume:
1. Highlight **Settings** and press **OK**.
2. Highlight **Sounds** and press **OK**.
3. Highlight **Ringer, Earpiece, Key Beep,** or **PWR On/Off** and press **OK**.
4. Highlight a volume setting and press **OK**.
Tip: You can adjust the ringer volume in standby mode (or the earpiece volume during a call) by using the volume keys on the side of your phone.

Selecting a Key Tone Length

Your phone offers you the option of selecting long or short tone lengths for key presses. Longer tone lengths may better facilitate tone recognition when dialing voicemail or other automated systems.
To select a tone length:
1. Highlight **Settings** and press **OK**.
2. Highlight **Sounds** and press **OK**.
3. Highlight **Tone Length** and press **OK**.
4. Highlight **Short** or **Long** and press **OK**.

Ringer Types

Ringer types help you identify incoming calls and messages. You can assign ringer types to individual phone book entries, types of calls, and types of messages.
_**Preprogrammed Ringers** include a variety of standard ringer types and familiar music.
_**Vibrating Ringer** alerts you to calls or messages without disturbing others.

Selecting Ringer Types for Voice Calls

Your STi Mobile phone provides a variety of ringer options which allow you to customize your ring and volume settings.
To select a ringer type for voice calls so you recognize when a certain type of call is coming in by the ringer:
1. Highlight **Settings** and press **OK**.
2. Highlight **Sounds** and press **OK**.
3. Highlight **Ringer Type** and press **OK**.
4. Highlight **Voice Calls** and press **OK**.

5. Highlight **With Caller ID, No Caller ID** press **OK**.
6. Highlight a ringer type and press **OK**. You will hear a preview of the ringer type when you highlight it.

Selecting Ringer Types for Messages

To select a ringer type for messages:
1. Highlight **Settings** and press **OK**.
2. Highlight **Sounds** and press **OK**.
3. Highlight **Ringer Type** and press **OK**.
4. Highlight **Messages** and press **OK**.
5. Highlight **Voicemail** or **Page** and press **OK**.
6. Highlight a ringer type and press **OK**. You will hear a preview of the ringer type when you highlight it.

Alert Notification

To enable or disable alert sounds for a variety of situations:
1. Highlight **Settings** and press **OK**.
2. Highlight **Sounds** and press **OK**.
3. Highlight **Alert** and press **OK**.
4. To select an option, highlight it and press **OK**.
_**Messages** to alert you when you receive a voicemail or page/text message.
_**Minute Beep** to play a beep once a minute while you are on a call. (The beep is not audible to the other party.)
_**Call Connect** to alert you when an outgoing call has been connected.
5. Highlight **On** or **Off** and press **OK**.

Silent Mode

There may be times when you need to silence your phone entirely. The phone's Silent Mode option allows you to mute all sounds without turning your phone off.
To activate Silent Mode:
_Press and hold the volume down key in standby mode. An alert will display informing you that the option will mute all sound. The screen will then display "Silent Mode."
To deactivate Silent Mode:
_Press and hold the volume up key in standby mode. An alert will inform you that the option will restore all sound.
Silent Mode may also be accessed through the phone's Settings menu:
1. Highlight **Settings** and press **OK**.
2. Highlight **Sounds** and press **OK**.
3. Highlight **Silent Mode** and press **OK**.
4. Highlight **On** or **Off** and press **OK**.

Display Settings

Changing the Backlight Time Length

The backlight setting lets you select how long the display screen and keypad are backlit after any key press is made.
To change the backlight setting:
1. Highlight **Settings** and press **OK**.
2. Highlight **Display** and press **OK**.
3. Highlight **Backlight** and press **OK**.
4. Highlight **8 Seconds, 15 Seconds, 30 Seconds, Off,** or **Always On** and press **OK**.
Note: Long backlight settings affect the battery's talk and standby times.

Changing the Greeting

The greeting can be up to twelve characters and is displayed on your phone's screen in standby mode.
To display or change your custom greeting:
1. Highlight **Settings** and press **OK**.
2. Highlight **Display** and press **OK**.
3. Highlight **Greeting** and press **OK**.
4. Highlight **Change** and press **OK**.
5. Press and hold **BACK** to clear the current greeting.
6. Enter your new greeting text. (See "Entering Text" on page 25.)
7. When you are finished, highlight **Save** and press **OK**. To discard your changes, highlight **Exit** and press **OK**.

Changing the Contrast

To adjust the contrast on the phone's display:
1. Highlight **Settings** and press **OK**.
2. Highlight **Display** and press **OK**.
3. Highlight **Contrast** and press **OK**.
4. Highlight a contrast level and press **OK**. The screen will display the effects of the settings as you highlight them.

Changing the Power On/Off and Screen Saver Display Options

Your new STi Mobile phone offers options for what you see on the display screen while powering on or off and as a screen saver while in standby mode.

Power On/Off

To assign an image for Power On or Power Off:
1. Highlight **Settings** and press **OK**.
2. Highlight **Display** and press **OK**.
3. Highlight **Screen** and press **OK**.
4. Highlight **Power On/Off** and press **OK**.
5. Highlight **Power On** or **Power Off** and press **OK**.
6. Highlight **Item 1, Item 2,** or **Item 3** and press **OK**.
7. To select an option, highlight it and press **OK**.
_**View** to see a preview of the selected item. (Press **OK** or **Back** to return to the option menu.)
_**Assign** to assign the selected item.

Screen Saver

To assign an image for Screen Saver mode:
1. Highlight **Settings** and press **OK**.
2. Highlight **Display** and press **OK**.
3. Highlight **Screen** and press **OK**.
4. Highlight **Screen Saver** and press **OK**.
5. Highlight **Images** and press **OK**.
6. Highlight **Item 1, Item 2,** or **Item 3** and press **OK**.
7. To select an option, highlight it and press **OK**.
_**View** to see a preview of the selected item. (Press **OK** or **Back** to return to the option menu.)
_**Assign** to assign the selected item.
To activate or deactivate Screen Saver mode:
1. Highlight **Settings** and press **OK**.
2. Highlight **Display** and press **OK**.
3. Highlight **Screen** and press **OK**.
4. Highlight **Screen Saver** and press **OK**.
5. Highlight **On/Off** and press **OK**.
6. Highlight **On** or **Off** and press **OK**.

Changing the Display Language

To change the language of your phone's display:
1. Highlight **Settings** and press **OK**.
2. Highlight **Display** and press **OK**.
3. Highlight **Language** and press **OK**.
4. Highlight **English** or **Spanish** and press **OK**.

Location Settings

Your STi Mobile phone is equipped with a Location feature which will allow the network to detect your position, making some STi Mobile applications easier to use. Turning Location off will hide your location from everyone except 911.
Note: Even if the Location feature is enabled, no service may use your location without your expressed permission.
To enable your phone's Location feature:
1. Highlight **Settings** and press **OK**.
2. Highlight **Location** and press **OK**.
3. You will see a disclaimer outlining your phone's Location feature. Press **OK** to continue.
4. Highlight **On** or **Off** and press **OK**.

When the Location feature is on, your phone's standby screen will display the icon. When Location is turned off, the icon will display.

Phone Setup Options

Call Answer Mode

To set the actions required to answer an incoming call:
1. From the main menu, highlight **Settings** and press **OK**.
2. Highlight **Setup** and press **OK**.
3. Highlight **Any key Answer** and press **OK**.
4. Highlight **On** or **Off** and press **OK**.
_**On** allows you to answer incoming calls by opening the phone or by pressing any key.
_**Off** requires you to press to answer all incoming calls.

Auto-Answer Mode

To answer calls when your phone is connected to an optional hands-free car kit:
1. From the main menu, highlight **Settings** and press **OK**.
2. Highlight **Setup** and press **OK**.
3. Highlight **Car Auto-Answer** and press **OK** .
4. To select an option, highlight it and press **OK**.
_**Off** to answer calls normally when connected to a hands-free car kit.
_**Auto Answer** to have the phone answer calls automatically after three rings when connected to a hands-free car kit.
Remember, your phone will answer all incoming calls in Auto Answer mode – even if you are not present.

Section 2C Setting Your Phone's Security

In This Section

_**Accessing the Security Menu**
_**Locking Your Phone**
_**Unlocking Your Phone**
_**Using Special Numbers**

By using the security setting on your STi Mobile phone, you receive peace of mind without sacrificing flexibility. With several options available, you can customize your phone to meet your personal needs.

Accessing the Security Menu

You must enter your lock code to view the Security menu.
To access the Security menu:
1. From the main menu, highlight **Settings** and press **OK**.
2. Highlight **Security** and press **OK**.
3. Enter your lock code. The Security menu is displayed.
Tip: If you can't recall your lock code, try using the last four digits of either your Social Security number or STi Mobile phone Number or try 0000. If none of these work, call STi Mobile Customer Care at 1-800-784-3277.

Locking Your Phone

When your phone is locked, you can only receive incoming calls or make calls to 911, STi Mobile Customer Care, or special numbers.
To lock your phone:
1. From the Security menu, highlight **Lock Phone** and press **OK**. (See "Accessing the Security Menu" on this page.)
2. Highlight **Lock Now** and press **OK**. A message will confirm that the phone is locked. When the phone returns to standby mode, **--Locked--** will appear on the display.

Unlocking Your Phone

To unlock your phone:
1. Highlight **Unlock** and press **OK**.
2. Enter your lock code.

Changing the Lock Code

To change your lock code:
1. From the Security menu, highlight **Change Lock Code** and press **OK**. (See “Accessing the Security Menu” on this page.)
2. Enter your new lock code.
3. Re-enter your new lock code.

Calling in Lock Mode

You can place calls to 911 and to your special numbers when in lock mode. (For information on special numbers, see “Using Special Numbers” on page 41.)
To place an outgoing call in lock mode:
_To call an emergency number or a special number, enter the phone number and press **OK**.
Tip: To dial a 911 emergency call in lock mode, you can also highlight **Call 911** and press **OK**.

Using Special Numbers

You can save four special numbers in addition to your Internal Phone Book entries (the same number may be in both directories). You can make and receive calls from special numbers even when your phone is locked.
To add or replace a special number:
1. From the Security menu highlight **Special #s** and press **OK**. (See “Accessing the Security Menu” on page 40.)
2. Highlight an entry location and press **OK**.
3. Enter or replace the special number.
4. Highlight **OK** and press **OK**.
Note: There are no Speed Dial options associated with special numbers.

Erasing the Internal Phone Book

To erase all the names and phone numbers in your Internal Phone Book:
1. From the Security menu, highlight **Erase Phonebook** and press **OK**. (See “Accessing the Security Menu” on page 40.)
2. A warning will display informing you that the action will erase the entire phone book content. If you wish to continue, highlight **Yes** and press **OK**.

Resetting Your Phone

Resetting the phone restores all the factory defaults, including the ringer types and display settings. The Internal Phone Book, Call History, Scheduler, and Messaging are not affected.
To reset your phone:
1. From the Security menu, highlight **Reset Phone** and press **OK**. (See “Accessing the Security Menu” on page 40.)
2. A warning will display informing you that settings will be restored to the factory defaults. If you wish to continue, highlight **Yes** and press **OK**.

Section 2D: Menus

Navigating Through Menus

In This Section

_**Menu Navigation**
_**Menu Structure**
_**Viewing Menus**

This section is a road map to using your STi Mobile phone. Every function and feature can be accessed through a menu. Take a few moments to learn your way around. You’ll find that it makes your phone easier to use.

Menu Navigation

The navigation key on your STi Mobile phone allows you to scroll through menus quickly and easily. The scroll bar at the right of the menu keeps track of your position in the menu at all times. To navigate through a menu, simply press the navigation key up or down to highlight menu options. To select an option, highlight it and press **OK**.

Menu Structure

Selecting Menu Items

As you navigate through the menu, menu options are highlighted. To select an option, simply highlight it and press **OK**.
For example, if you want to view your last incoming call:
1. From the main menu, highlight **Call History** and press **OK**. (It may already be highlighted.)
2. Highlight **Incoming Calls** and press **OK**. The most recent calls you have received will be displayed on the screen.

Backing Up Within a Menu

To go to the previous menu:
_Press **BACK**.
To return to standby mode:
_Press **END**.

Viewing the Menus

Menu Diagram
The following list outlines your phone's menu structure.
Call History
Outgoing Calls
Incoming Calls
Missed Calls
Erase Calls
Outgoing Calls
Incoming Calls
Missed Calls
All Calls
Phone Book
Find Name
Add New Entry
My Phone #
Speed Dial #s
Services Cust. Care/Dir Assist/Account Info/Prepaid
Messages
Page/Text
Edit Folder
Settings
Auto Save On/Off
Auto Delete On/Off
2 Min Alert On/Off
Erase All Msgs Yes/No
Voicemail
Call Voicemail
Clear Count Yes/No
Settings
Sounds
Audio Volume
Ringer High/Medium High/Medium Low/Low/
Vibrate/Off
Earpiece High/Medium High/Medium Low/Low
Key Beep High/Medium High/Medium Low/Low/Off
PWR On/Off High/Low/Off
Tone Length Short/Long
Ringer Type
Voice Calls

With Caller ID (ring types)
No Caller ID (ring types)
Messages
Voicemail (ring types)
Page (ring types)
Alert
Service Change On/Off
Messages On/Off
Minute Beep On/Off
Call Connect On/Off
Silent Mode On/Off
Display
Backlight 8 Seconds/15Seconds/30 Seconds/
Off/Always On
Greeting Keep/Change
Contrast High/Medium High/Medium/Medium Low/Low
Screen
Power On/Off
Power On Item 1/Item 2/Item 3(View/Assign)
Power Off Item 1/Item 2/Item 3(View/Assign)
Screen Saver
Images Item 1/Item 2/Item 3(View/Assign)
On/Off On/Off
Language English/Spanish
Set Mode STi Mobile/Automatic
Call Guard On/Off
Location On/Off
Security (Enter Lock Code)
Lock Phone
Change Lock Code
Special #s
Erase Phonebook Yes/No
Reset Phone Yes/No
Setup
Anykey Answer On/Off
Car Auto-Answer Off/Auto Answer
Phone Info
Tools
Scheduler
Add Event
Erase Event
Today
Week View
Month View
Purge
Purge All
Information
(Help)
Calculator
Games
Mobile Hawk
Black Jack 2
Game Options
Sound High/Medium High/Medium Low/Low/Off
BackLight On/Off

Section 2E Managing Call History

In This Section

_**Viewing History**
_**Call History Options**
_**Making a Call From Call History**

_**Saving a Phone Number From Call History**
_**Erasing Call History**
The Call History keeps track of incoming calls; calls made from your STi Mobile phone, and missed calls. This section guides you through accessing and making the most of your Call History.

Viewing Call History

You'll find the Call History feature very helpful. It is a list of the last 10 phone numbers (or Internal Phone Book entries) for calls you placed, accepted, or missed. Call History makes redialing a number fast and easy. It is continually updated as new numbers are added to the beginning of the list and the oldest entries are removed from the bottom of the list.
Each entry contains the phone number (if it is available) and Internal Phone Book entry name (if the phone number is in your Internal Phone Book). Duplicate calls (same number and type of call) may only appear once on the list.
To view a Call History entry:
1. From the main menu, highlight **Call History** and press **OK**.
2. Highlight **Outgoing Calls, Incoming Calls,** or **Missed Calls** and press **OK**.
3. Highlight the Call History entry you wish to view and press **OK**.

Call History Options

For additional information and options on a particular call, highlight a Call History entry and press **OK**. To select an option, highlight it and press **OK**.
_**Call** to dial the phone number (if available).
_**Phonebook Info** to display the entry's Internal Phone Book entry (if the number is in your Internal Phone Book).
– or –
_**Save** to save the phone number if it is not already in your Internal Phone Book. (See "Saving a Phone Number From Call History" on page 54.)
_**Time/Date** to see the time and date of the selected entry.
_**Prepend** to add numbers to the beginning of the phone number. (See "Pre-pending a Phone Number From Call History" on page 55.)
_**Erase** to erase the entry from Call History.
_**Next** to display the next Call History entry.
_**Previous** to display the previous Call History entry.
Tip: You can also view the next Call History entry by pressing the navigation key right or view the previous entry by pressing the navigation key left.

Making a Call From Call History

To place a call from Call History:
1. From the main menu, highlight **Call History** and press **OK**.
2. Highlight **Outgoing Calls, Incoming Calls,** or **Missed Calls** and press **OK**.
3. Highlight the entry you wish to call and press **OK**.
4. Highlight **Call** and press **OK**.
Note: You cannot make calls from Call History to entries identified as No ID or Restricted. Calls labeled Data or Fax can only be dialed through a personal computer.

Saving a Phone Number From Call History

Your STi Mobile phone can store up to 99 Internal Phone Book entries. Phone Book entries can store up to a total of five phone numbers and each entry's name can contain sixteen characters.
To save a phone number from Call History:
1. From the main menu, highlight **Call History** and press **OK**.
2. Highlight **Outgoing Calls, Incoming Calls,** or **Missed Calls** and press **OK**.
3. Highlight the number you wish to save and press **OK**.
4. Highlight **Save** and press **OK**.
5. Highlight a label for the number and press **OK**.
6. Enter a name for the Internal Phone Book entry (see "Entering Text" on page 25) and press **OK**. You may also add the number to an existing phone book entry by highlighting the desired entry and pressing, as long as the entry contains fewer than five numbers and there is no other number within the entry with the same label as the new number.
7. To select an option, highlight it and press **OK**.
_**Done** to save the entry.

_**Set Speed Dial** to select a speed dial location for the entry.
Highlight an available location and press **OK**. (See “Using One-Touch/Two-Touch Speed Dialing” on page 25.) After you have saved the number, the new Internal Phone Book entry is displayed. (See “Internal Phone Book Entry Options” on page 59.)
Note: You cannot save phone numbers already in your Internal Phone Book or from calls identified as No ID or Restricted.

Prepending a Phone Number From Call History

If you need to make a call from Call History and you happen to be outside your local area code, you can add the appropriate prefix by following these steps:
1. From the main menu, highlight **Call History** and press **OK**.
2. Highlight **Outgoing Calls, Incoming Calls,** or **Missed Calls** and press **OK**.
3. Highlight the number you wish to prepend and press **OK**.
4. Highlight **Prepend** and press **OK**.
5. Enter the digits or pauses (see below) you wish to add to the number. If you want to save the number, select the **Save** option. If not, the changes apply only for the current call.
6. To select an option, highlight it and press **OK**.
_**Call** to dial the phone number.
_**Save** to save the phone number in your Internal Phone Book.
_**Hard Pause** to insert a hard pause. (See “Dialing and Saving Phone Numbers With Pauses” on page 23.)
_**2-Second Pause** to insert a two-second pause. (See “Dialing and Saving Phone Numbers With Pauses” on page 23.)

Erasing Call History

To erase individual Call History entries, see “Call History Options” on page 52.
To erase Call History:
1. From the main menu, highlight **Call History** and press **OK**.
2. Highlight **Erase Calls** and press **OK**.
3. Highlight **Outgoing Calls, Incoming Calls, Missed Calls,** or **All Calls** and press **OK**.
4. A confirmation prompt will appear (for example, “Erase Missed?”). Highlight **Yes** and press **OK**.

Section 2F Using the Internal Phone Book

In This Section

_**Internal Phone Book Entry Options**
_**Adding a New Internal Phone Book Entry**
_**Finding Internal Phone Book Entries**
_**Selecting a Ringer Type**
_**Dialing STi Mobile Customer Care**

Now you know the basics that make it easier to stay in touch with people and information. This section helps you make the most of your contacts and time.

Displaying an Internal Phone Book Entry

Your new STi Mobile phone’s Internal Phone Book helps you make the most of your time by storing and organizing important numbers and information about your contacts. There are several ways to find and display Internal Phone Book entries. Follow the steps outlined below to display entries:

Finding Names

To find and display an Internal Phone Book entry by name:
1. From the main menu, highlight **Phone Book** and press **OK**.
2. Highlight **Find Name** and press to display a list of all current entries.
Shortcut: Press the navigation key left to display the “Find Name” list of all current entries.
3. Scroll to highlight the entry you wish to display and press to display it. You may also narrow your search by entering any part of the entry’s name to select it and then press to display the entry.

Note: When entering text to search for an entry, the **Abc** mode of text entry applies. (See "Entering Text" on page 25.) The phone searches for any consecutive string of letters in an entry's name, so entering "r" or "er" would find "Jerry"; entering "jr" would not.

Finding Numbers

To find and display an Internal Phone Book entry by phone number:
1. Enter a number or a string of numbers in standby mode.
2. Highlight **Find** and press **OK**.
3. Highlight the number contained in the Internal Phone Book entry you wish to display and press to display the entry.

Finding Speed Dial Numbers

To find and display an Internal Phone Book entry using its speed dial number:
1. Enter a speed dial number from standby mode.
2. Highlight the Internal Phone Book entry name and press to display the entry.

Internal Phone Book Entry Options

To access an Internal Phone Book Entry's options, display the entry (see above). The options menu will display below the entry's name and default phone number. To select an option, highlight it and press **OK**.
_**Call** to dial the entry's selected (default) phone number.
_**[Additional Phone Numbers]** to select an alternate phone number (if the entry has more than one phone number).
_**Add Phone #** to add a phone number to the entry. (See "Adding a Phone Number to an Internal Phone Book Entry" on page 60.)
_**Edit Number** to change the selected phone number or add or delete its speed dial setting. (See "Editing an Internal Phone Book Entry's Phone Number" on page 61.)
_**Edit Entry** to change the entry's default number, ringer type, name, email, or secret mode. (See "Editing an Internal Phone Book Entry" on page 62.)
_**Erase Number** to delete one of the entry's alternate phone numbers. (You must first select an alternate phone number by highlighting it and pressing.) You cannot delete an entry's default phone number.
_**Erase Entry** to delete the entry and all its information from your Internal Phone Book.
Tip: You can view the next entry by pressing the navigation key right or view the previous entry by pressing the navigation key left.

Adding a New Internal Phone Book Entry

Your STi Mobile phone can store up to 99 Internal Phone Book entries. Phone book entries can store up to a total of five phone numbers and an entry's name can contain sixteen characters.
To add a new entry:
1. From the main menu, highlight **Phone Book** and press **OK**.
2. Highlight **Add New Entry** and press **OK**.
3. Enter a name for the entry or highlight **Save w/o Name** and press **OK**. (See "Entering Text" on page 25.)
4. Enter a phone number, highlight **Next Step** and press **OK**.
5. Highlight a label for the entry and press **OK**.
6. To select an option, highlight it and press **OK**.
_**Done** to save the entry.
_**Set Speed Dial** to save the entry in an available speed dial location. Highlight an available location and press **OK**. (See "Using One-Touch/Two-Touch Speed Dialing" on page 25.) After you have saved the number, the new Internal Phone Book entry is displayed. (See "Internal Phone Book Entry Options" on page 59.)

Adding a Phone Number to an Internal Phone Book Entry

To add a phone number to an entry:
1. Display an Internal Phone Book entry. (See "Displaying an Internal Phone Book Entry" on page 58.)
2. Highlight **Add Phone #** and press **OK**.
3. Enter the phone number with area code, highlight **Next Step** and press **OK**.
4. Select a label for the phone number and press **OK**.
5. To select an option, highlight it and press **OK**.
_**Done** to save the entry.
_**Set Speed Dial** to save the entry in an available speed dial location. Highlight an available location and press **OK**. (See "Using One-Touch/Two-Touch Speed Dialing" on page 25.)
After you have saved the number, the Internal Phone Book entry is displayed. (See "Internal Phone Book Entry Options" onpage 59.)

Note: Phone numbers labeled Fax or Data can only be dialed through a personal computer.

Editing an Internal Phone Book Entry's Phone Number

To edit an entry's phone number:
1. Display an Internal Phone Book entry. (See "Displaying an Internal Phone Book Entry" on page 58.)
2. If you wish to edit the entry's default phone number, proceed to step 3. If you wish to edit an alternate number, highlight it and press **OK**.
3. Highlight **Edit Number** and press **OK**.
4. To select an option, highlight it and press **OK**.
_**Edit Number** to change the entry's phone number. Press to erase the current number one digit at a time, or press and hold to erase the entire number. Follow the steps outlined in "Adding a Phone Number to an Internal Phone Book Entry" on page 60.
_**Set Speed Dial** to assign the number to an available speed dial location or **Erase Speed Dial** to erase the number's speed dial assignment (if already assigned). (See "Using One-Touch/Two-Touch Speed Dialing" on page 25.)
After you have saved the number, the Internal Phone Book entry is displayed. (See "Internal Phone Book Entry Options" on page 59.)

Editing an Internal Phone Book Entry

To make changes to an entry:
1. Display an Internal Phone Book entry. (See "Displaying an Internal Phone Book Entry" on page 58.)
2. Highlight **Edit Entry** and press **OK**.
3. To select an option, highlight it and press **OK**.
_**Set Default #** to change the entry's default phone number. Highlight a number and press **OK**.
_**Ringer Type** to select a ringer type to play when you receive a call from the entry. Highlight a ringer type and press **OK**. (You will hear a preview of the ringer type when highlighted.)
_**Name** to edit the entry's name. (See "Entering Text" on page 25.)
_**E-Mail** to add or change the entry's email address. (See "Entering Text" on page 25.)
_**Secret Mode** to set the entry's secret mode status. (See "Secret Internal Phone Book Entries" on page 63.)
After you have saved the changes, the Internal Phone Book entry is displayed. (See "Internal Phone Book Entry Options" on page 59.)

Selecting a Ringer Type for an Entry

You can assign a ringer type to an Internal Phone Book entry so you can identify the caller by the ringer type. (See "Ringer Types" on page 31.)
To select a ringer type for an entry:
1. Display an Internal Phone Book entry. (See "Displaying an Internal Phone Book Entry" on page 58.)
2. Highlight **Edit Entry** and press **OK**.
3. Highlight **Ringer Type** and press **OK**.
4. Use your navigation key to scroll through available ringers (when you highlight a ringer type a sample ringer will sound). Highlight your desired ringer and press **OK**.
5. Press the left softkey button (Done) to save the new ringer type.

Secret Internal Phone Book Entries

You can hide an entry's phone number(s) and require your lock code to edit the entry by making it secret. The entry name is still displayed, but the entry's phone numbers are replaced by "(SECRET)".
To make an entry secret:
1. Display an Internal Phone Book entry. (See "Displaying an Internal Phone Book Entry" on page 58.)
2. Highlight **Edit Entry** and press **OK**.
3. Highlight **Secret Mode** and press **OK**.
4. The prompt, "Make Secret?," will display. Highlight **Yes** and press .
After you have saved the changes, the Internal Phone Book entry is displayed. (See "Internal Phone Book Entry Options" on page 59.)
To make an entry public:
1. Display a secret Internal Phone Book entry.
2. Highlight **Edit Entry** and press **OK**.
3. Enter your lock code.
4. Highlight **Secret Mode** and press **OK**.
5. The prompt, "Make Secret?," will display. Highlight **No** and press **OK**.

Tip: If you can't recall your lock code, try using the last four digits of either your Social Security number or STi Mobile phone number or try 0000. If none of these work, call STi Mobile Customer Care 1-800-784-3277.
After you have saved the changes, the Internal Phone Book entry is displayed. (See "Internal Phone Book Entry Options" on page 59.)

Managing Speed Dial Settings

In addition to assigning and deleting speed dial locations through the Edit Number menu (see "Editing an Internal Phone Book Entry's Phone Number" on page 61), you can manage speed dial settings directly through the Speed Dial #s menu.
To manage your speed dial settings:
1. From the main menu, highlight **Phone Book** and press **OK**.
2. Highlight **Speed Dial #s** and press **OK**.
3. Highlight a location or enter one using your keypad and press.
4. To select an option, highlight it and press **OK**.
_**Set Speed Dial** to assign a number to the selected location.
To assign a number, highlight an Internal Phone Book entry and press and then highlight a number from the entry and press **OK**.
_**Next Empty** to go to the next available speed dial location.
_**Erase Speed Dial** to erase the speed dial number assigned to the selected location.
_**Erase All** to erase all speed dials.
_**(Exit)** to return to the main menu.

Using the Scheduler, Calculator, and Games

In This Section

_**Adding an Event to the Scheduler**
_**Event Alerts**
_**Viewing Events**
_**Using the Calculator**
_**Playing Games**

Your STi Mobile phone is equipped with several tools; including personal information management features that help you manage your busy lifestyle. These features turn your phone into a time management planner that helps you keep up with your contacts, schedules, and commitments. It takes productivity to a whole new level.

Using the Scheduler

Adding an Event to the Scheduler

Your Scheduler helps organize your time and reminds you of important events.
To add an event:
1. From the main menu, highlight **Tools** and press **OK**.
2. Highlight **Scheduler** and press **OK**.
3. Using your navigation key, highlight the day to which you want to add a scheduled event and press **OK**.
Tip: Press the navigation key or volume button up or down to scroll by week through the Scheduler calendar.
4. Highlight **Add Event** and press **OK**.
5. Enter a title, highlight **Next Step,** and press **OK**. (See "Entering Text" on page 25.)
6. Using your keypad, enter the time and date of the event (which are displayed at the top of the screen). To toggle between A.M. and P.M., highlight **AM/PM** and press **OK**.
7. To select an option, highlight it and press **OK**.
_**Done** to save the event in your Scheduler.
_**Ringer Type** to select a ringer to play when an alarm is scheduled for the event. To select a ringer, highlight it and press. You will hear a preview of the ringer when you highlight it
_**Edit Alarm** to schedule the event's alarm. (The default setting is **10 Min. Before**.) Highlight an alarm setting (**On Time, 10 Min. Before, 30 Min. Before, 1 Hour Before,** or **No Alarm**) and press **OK**.
_**Edit Repeat** to edit the event's repeating status. (The default setting is **No Repeat**.) Highlight a repeat setting (**No Repeat, Daily, Weekly, Monthly** or **Yearly**) and press **OK**.
_**Exit** to return to the main menu without saving the event.
8. To schedule the event, highlight **Done** and press **OK**.

Event Alerts

There are several ways your STi Mobile phone alerts you of scheduled events:
_By playing the assigned ringer type.
_By illuminating the backlight.
_By flashing the LED.
_By displaying the event's description, time, and date.

Event Alert Menu

When your phone is turned on and you have an event alarm scheduled, your phone alerts you and displays the event summary. Press **OK** to display the event alert menu.
To select an option, highlight it and press **OK**.
_**OK** to clear the alarm.
_**View Detail** to display the event's date, time, alarm, repeating status, and title.
_**Snooze** to repeat the alarm in five minutes.
_**Erase** to delete the event from your Scheduler. Highlight **Yes** and press to confirm the deletion.

Viewing Events and Event Options

To view your scheduled events:
1. From the main menu, highlight **Tools** and press **OK**.
2. Highlight **Scheduler** and press **OK**.
3. Using your navigation key, highlight the day for which you want to view scheduled events and press **OK**.
Tip: In Week View, the number of events scheduled is displayed under days with scheduled events. In Month View, days with events scheduled are underlined.
4. Scheduled events are listed in chronological order above the Scheduler menu options. To view an event's details, highlight the event and press **OK**.
5. To display event options, press again. To select an option, highlight it and press **OK**.
_**View Detail** to display the event's date, time, alarm, repeating status, and title.
_**Erase** to delete the event from your Scheduler. Highlight **Yes** and press to confirm the deletion.
_**Edit Content** to change the event's title. (See "Editing an Event's Title" on page 68.)
_**Change Settings** to edit the event's settings. (See "Editing an Event's Settings" on page 69.)
_**(Help)** to display Scheduler help.
_**Next Event** to display the next event.
_**Prev Event** to display the previous event.

Editing an Event's Title

To edit a scheduled event's title:
1. From the Scheduler menu, highlight an event and press **OK**. (See "Viewing Events and Event Options" on page 67.)
2. Press **OK** to display the event options.
3. Highlight **Edit Content** and press **OK**.
4. Press **OK** to erase the current title one letter at a time, or press and hold to erase the entire title.
5. Enter a new title and press **OK**. (See "Entering Text" on page 25.)
6. To save the new title, highlight **Done** and press **OK**.

Editing an Event's Settings

Editing an Event's Ringer Type

To edit the ringer type assigned to a scheduled event:
1. From the Scheduler menu, highlight an event and press **OK**. (See "Viewing Events and Event Options" on page 67.)
2. Press **OK** to display the event options.
3. Highlight **Change Settings** and press **OK**.
4. Highlight **Ringer Type** and press **OK**.
5. Highlight a ringer type and press **OK** to assign it to the event. You will hear a preview of the ringer when you highlight it.
6. To save the new setting, highlight **Done** and press **OK**.

Editing an Event's Alarm

To edit the alarm setting for a scheduled event:

1. From the Scheduler menu, highlight an event and press **OK**. (See "Viewing Events and Event Options" on page 67.)
2. Press to display the event options.
3. Highlight **Change Settings** and press **OK**.
4. Highight **Edit Alarm** and press **OK**.
5. To select an option, highlight it and press **OK**.
_**On Time** to schedule the alarm to play at the time of the scheduled event.
_**10 Min. Before** to schedule the alert for 10 minutes before the event.
_**30 Min. Before** to schedule the alert for 30 minutes before the event.
_**1 Hour Before** to schedule the alert for an hour before the event.
_**No Alarm** to schedule no alarm for the event.
6. To save the new setting, highlight **Done** and press **OK**.

Editing an Event's Repeating Status

To edit the repeating status for a scheduled event:
1. From the Scheduler menu, highlight an event and press **OK**. (See "Viewing Events and Event Options" on page 67.)
2. Press to display the event options.
3. Highlight **Change Settings** and press **OK**.
4. Highlight **Edit Repeat** and press **OK**.
5. To select an option, highlight it and press **OK**.
_**No Repeat** to schedule a one-time event.
_**Daily** to repeat the event every day.
_**Weekly** to repeat the event every week.
_**Monthly** to repeat the event every month.
_**Yearly** to repeat the event annually.
6. To save the new setting, highlight **Done** and press **OK**.

Erasing a Day's Events

To erase a scheduled day's events:
1. From the main menu, highlight **Tools** and press **OK**.
2. Highlight **Scheduler** and press **OK**.
3. Using your navigation key, highlight the day for which you would like to erase events and press **OK**.
4. Highlight **Erase Events** and press **OK**.
5. Highlight **Yes** and press **OK**.
Note: If the day for which you are erasing events contains a repeating event, you will receive the following prompt: "This will erase all repeating occurrences of this item(s)." Press **OK**. If you wish to erase all occurrences of the event, highlight **Yes** and press **OK** if not, highlight **No** and press **OK**.

Going to Today's Scheduler Menu

_If you are viewing the Scheduler menu for another date and wish to return to the menu for today's date, highlight **Today** and press OK.

Displaying the Week or Month View

_If you are viewing the Scheduler menu for a selected day and would like to view the week or month view containing that day, highlight **Week View** or **Month View** and press **OK**. The setting will be saved the next time you access your Scheduler.

Purging Events

To delete events scheduled before a specific time and date:
1. From the main menu, highlight **Tools** and press **OK**.
2. Highlight **Scheduler** and press **OK**.
3. Using your navigation key, highlight the date before which you would like to purge Scheduler events and press **OK**.
4. Highlight **Purge** and press **OK**.
5. A confirmation prompt will display. Highlight **Yes** and press **OK**.
Note: If the first occurrence of a repeating event falls before the date for which you are purging events, all subsequent occurrences of the repeating event will also be deleted.

Purging All Events

To delete all scheduled events:
1. From the main menu, highlight **Tools** and press **OK**.
2. Highlight **Scheduler** and press **OK**.
3. Press again to access the Scheduler menu.
4. Highlight **Purge All** and press **OK**.
5. A confirmation prompt will display. Highlight **Yes** and press **OK**.

Viewing Scheduler Memory Space

To view available and used Scheduler memory space:
1. From the main menu, highlight **Tools** and press **OK**.
2. Highlight **Scheduler** and press **OK**.
3. Press again to access the Scheduler menu.
4. Highlight **Information** and press **OK**.

Viewing Scheduler Help

To display a key function diagram for Scheduler use:
1. From the main menu, highlight **Tools** and press **OK**.
2. Highlight **Scheduler** and press **OK**.
3. Press again to access the Scheduler menu.
4. Highlight **(Help)** and press **OK**.

Using the Calculator

Your phone comes with a built-in calculator function. To use this feature, follow these easy steps:
1. From the main menu, highlight **Tools** and press **OK**.
2. Highlight **Calculator** and press **OK**.
3. Enter numbers using your keypad. Press "#" to enter a decimal point. If you make a mistake while entering a number, press **BACK** to erase it one digit at a time, or press and hold **BACK** to erase the entire entry.
4. Mathematical functions may be assigned using the navigation key. The display screen shows a diagram of the functions' corresponding locations. Press "*****" (shift) to display additional functions.
5. Press **OK** to complete your calculation.

Playing Games

Your new STi Mobile phone includes two built-in games to entertain you in your spare time: **Mobile Hawk**, an action-packed helicopter battle game, and **Black Jack 2** a hand-held version of the popular casino favorite.
To play a game on your STi Mobile phone:
1. From the main menu, highlight **Tools** and press **OK**.
2. Highlight **Games** and press **OK**.
3. Highlight **Mobile Hawk** or **Black Jack 2** and press **OK**.
4. To select an option, press the corresponding number key.
_**New Game** to start a new game.
_**High Score** to display the game's high scores.
Press to return to the game's menu.
_**Key Info.** to display a diagram of the game's function keys. Press to return to the game's menu.
_**Continue** to continue a previously saved game.

Adjusting Games Settings

To adjust your phone's Games settings:
1. From the main menu, highlight **Tools** and press **OK**.
2. Highlight **Games** and press **OK**.
3. Highlight **Game Options** and press **OK**.
4. To select an option, highlight it and press **OK**.
_**Sound** to adjust the volume level for games. Highlight a volume level and press **OK**.
Tip: You can also adjust the sound level during game play by pressing the volume button on the side of your phone.
_**BackLight** to adjust the backlight setting for games.
Highlight **On** or **Off** and press **OK**. This setting will apply to games only.
Tip: You can also turn the Backlight on or off during game play by pressing **OK**.

Section 3 Using STi Mobile Service Features

Section 3A STi Mobile Service Features:

The Basics

In This Section

_**Using Voicemail**
_**Receiving STi Mobile Messages**
_**Using Caller ID**

Now that you've mastered your phone's fundamentals, it's time to explore the messaging and calling features that enhance your STi Mobile Service.

Messaging Basics

Alerts When You Have Messages

There are several ways your STi Mobile phone alerts you to new messages:
_By displaying a message on the screen.
_By sounding the assigned ringer type.
_By the LED blinking red.
_By displaying at the top of your screen for voicemail messages, for text messages, or for both voice and text messages.

Message Types

There are two types of messaging features available from your STi Mobile phone's menu. You can receive voicemail and STi Mobile Messages (also known as page/text or SMS messages) as long as your phone has enough memory to store them.
_**Voicemail** automatically captures calls when you can't answer your phone or it is turned off. The voicemail system sends a notification to your phone when you have new voice messages and an asterisk (*) is displayed in front of the **Voicemail** menu option. (See "Using Voicemail" on page 79.)
_**STi Mobile Messages** (appear on your phone's menu as **Page** under the **Messages** option) include numeric pages. (See "STi Mobile Messages" on page 86.)

Using Voicemail

Setting Up Your Voicemail

All unanswered calls to your STi Mobile phone are automatically transferred to voicemail, even if your phone is in use or turned off. Therefore, you will want to set up your STi Mobile voicemail and personal greeting as soon as your STi Mobile phone is activated.
To set up voicemail:
1. Press and hold **1**.
2. Follow the system prompts to create your pass code, record your greeting, record your name announcement, and choose whether to activate One-Touch Message Access (a feature that lets you access messages by pressing and holding and bypasses the need for you to enter your pass code).
Note: The voicemail setup process may vary in certain Affiliate areas.

Voicemail Notification

There are several ways your STi Mobile phone alerts you:
_By displaying a message on the screen.
_By sounding the assigned ringer type.
_By the LED blinking red.
_By displaying at the top of your screen.

New Voicemail Message Alerts

When you receive a new voicemail message, your phone alerts you and prompts you to call your voicemail. To call your voicemail, press and hold **1**. To display your Missed Log, press **End** or **Back.**
Important: When you are roaming off the enhanced STi Mobile Coverage Area, you may not receive notification of new voicemail messages. It is recommended that you periodically check your voicemail by dialing 1 + area code + your STi Mobile phone number. When your voicemail answers, press **OK** and enter your pass code.
Note: Your phone accepts messages even when it is turned off. However, you are only notified of new messages when your phone is turned on and you are in a STi Mobile Service Area.

Retrieving Your Voicemail Messages

You can review your messages directly from your STi Mobile phone or from any other touch-tone phone. To dial from your STi Mobile phone, you can either speed dial your voicemail or use the menu keys.

Using One-Touch Message Access:

_Press and hold **1**. Follow the system prompts.
Using the Menu Keys on Your STi Mobile phone to Access Your Messages:
1. From the main menu, highlight **Voicemail** and press **OK**.
2. Highlight **Call Voicemail** and press **OK**.
Note: You are charged for airtime minutes when you are accessing your voicemail from your STi Mobile phone.

Using a Phone Other Than Your STi Mobile Phone to Access Messages:

1. Dial your STi Mobile phone number.
2. When your voicemail answers, press ***shift.**
3. Enter your pass code.
Tip: When you call into voicemail you first hear the header information (date, time, and sender information) for the message. To skip directly to the message, press **4** during the header.

Voicemail Button Guide

Here's a quick guide to your keypad functions while listening to voicemail messages. For further details and menu options, see
"Voicemail Menu Key" on page 85.
Date/Time **1**
Send **2**
Reply Advance **3**
Replay **4**
Forward **6**
Erase 7
Call Back/Reply **8**
Save **9**
Cancel ***Shift**
Help **0**
Skip # **Skip**

Voicemail Options

Your STi Mobile phone offers several options for organizing and accessing your voicemail.

Using Expert Mode

Using the Expert Mode setting for your personal voicemail box helps you navigate through the voicemail system more quickly by shortening the voice prompts you hear at each level.
To turn Expert Mode on or off:
1. Press and hold **1** to access your voicemail. If your voicemail box contains any new or saved messages, press ***shift** to access the main voicemail menu.
2. Following the system prompts, press **3** to change your Personal Options.
3. Press **4** for Expert Mode.
4. Press **1** to turn Expert Mode on or off.

STi Mobile Callback

Return a call after listening to a message without disconnecting from voicemail.
1. After listening to a message, press **8**.
2. Enter the phone number.

3. Once the call is complete, you're returned to the voicemail main menu.

Voicemail-to-Voicemail Message

Record and send a voice message to other STi Mobile voicemail users.
1. From the main voicemail menu, press **2** to send a message.
2. Follow the voice prompts to enter the phone number.
3. Follow the voice prompts to record and send your voice message.

Voicemail-to-Voicemail Message Reply

Reply to a voice message received from any other STi Mobile voicemail user.
1. After listening to a voice message, press **2**.
2. Follow the voice prompts to record and send your reply.

Voicemail-to-Voicemail Receipt Request

Receive confirmation that your voice message has been listened to when you send, forward or reply to other STi Mobile users.
1. After you have recorded a message, press **1**to indicate you are satisfied with the message you recorded.
2. Press **4** to mark receipt requested.
3. Press **1** to send your voicemail message.

Continue Recording

_Before pressing **1** to indicate you are satisfied with the message you recorded, press 4 to continue recording.

Clearing the Message Icon

Your phone may temporarily continue to display the message icon after you have checked your voice messages. To clear the icon from the display screen:
1. From the main menu, highlight **Voicemail** and press **OK**.
2. Highlight **Clear Count** and press **OK**.
3. A confirmation prompt will display. Highlight **Yes** and press **OK**.

Voicemail Menu Key

1 Listen
1 Envelope Information
2 Send a Reply Message
3 Advance 8 Seconds
4 Rewind to Start
7 Erase Message
8 Callback/Place Call
9 Save Message
2 Send a Message
3 Personal Options
1 Notification Options
1 Phone Notification
2 Numeric Paging to a STi Mobile Phone
***Shift** Return to Personal Options Menu
2 Administrative Options
1 Skip Passcode
2 Autoplay
3 Message Date & Time On/Off
4Change Passcode
***Shift** Return to Personal Options Menu
3Greetings
1Personal Greetings
Recorded Name
***Shift** Return to Personal Options Menu
8 Place a Call
***Shift** Exit Voicemail Menu

STi Mobile Messages

Now, through the enhanced STi Mobile Coverage Area, you can receive numeric pages on your STi Mobile phone.

Numeric Pages

Callers can send a numeric page to your phone when they reach your voicemail box. Numeric paging to a STi Mobile phone is included at no additional cost.

Note: The numeric paging option for your STi Mobile phone must be turned on for your phone to receive pages. This option can be set by entering your Voicemail menu Personal Options area. (See “Voicemail Menu Key” on page 85 for more information.)

Message Notification

There are several ways your STi Mobile phone alerts you of new messages:

_By displaying the alert, “New Message,” on the screen.
_By sounding the assigned ringer type.
_By the LED blinking red.
_By displaying at the top of the screen.

Receiving New Messages

When you receive a new numeric page, your phone displays the alert “New Message” along with the date and time the message arrived.

To select an option, highlight it and press **OK**.

_**View** to display the new message. The sender information, phone number (if numeric page), subject and message will display. Press **OK** to display message options.
_**Ignore** to return to the phone’s main menu. The new message will be saved in the appropriate location in the Messages menu.

Viewing Saved Messages

To view saved numeric pages.

1. From the main menu, highlight **Messages** and press **OK**.
2. Highlight **Page/Text** or a folder name and press **OK**.
3. Highlight the message you wish to display and press **OK**.

Unread messages will be marked with an asterisk (*).

Storing Messages

Your STi Mobile phone can store up to 50 messages. When message memory is 90% full, a warning displays in the messages menu. (To delete stored messages, see “Message Options” on page 88.)

When your phone reaches its message capacity, it automatically deletes the oldest messages as new messages arrive.

Note: Unread and locked messages will not be automatically deleted when messages capacity has been reached. If your phone has a combined 50 unread and locked messages, any new text messages will be returned without notification.

Message Options

After displaying a numeric page, or update, press **OK** to display the options menu.

To select an option, highlight it and press **OK**.

_**Extract Number** to extract a phone number from a message.
(See “Extracting Phone Numbers From a Message” on page 88.)
_**Erase** to delete the message.
_**Create Folder** to create a new folder to store the message. (See “Creating Folders for Messages” on page 90.)
_**Lock Message** to save the message from being deleted when the maximum number of stored messages has been reached. (Locked messages display an “@” symbol before the message.)
_**Read Again** to display the message.
_**Exit** to return to the main menu.

Extracting Phone Numbers From a Message

After you display a message, press to display message options.

To extract a phone number contained in the message:

1. Highlight **Extract Number** and press **OK**. All the phone numbers contained in the message are displayed. (If there are no phone numbers to extract from the message, the following message displays: “There is nothing to extract.”)
2. Highlight the number you wish to extract and press **OK**.
3. To select an option, highlight it and press **OK**.
_**Call** to dial the phone number.
_**Save** to save the phone number in your Internal Phone Book. (See “Internal Phone Book Entry Options” on page 59.)
_**Next Number** to display the next phone number contained in the message (if applicable).
Section 3: Using STi Mobile Service Features
_**Prepend** to add numbers to the beginning of the phone number. (See “Prepending a Phone Number From a Message” on page 89.)
_**Exit** to return to the main menu.

Prepending a Phone Number From a Message

After you display a message, press to display message options.
If you happen to be outside your local area code and need to add a prefix to a phone number:
1. Highlight **Prepend** and press **OK**.
2. Enter the digits or pauses (see below) you want to add to the number. If you want to save the number, select the Save option. If not, the changes only apply to the current call.
3. To select an option, highlight it and press **OK**.
_**Call** to dial the phone number.
_**Save** to store the phone number in your Internal Phone Book.
_**Hard Pause** to insert a hard pause. (See “Dialing and Saving Phone Numbers With Pauses” on page 23.)
_**2-Second Pause** to insert a 2-second pause. (See “Dialing and Saving Phone Numbers With Pauses” on page 23.)
_**Exit** to return to the previous screen.
Section 3: Using STi Mobile Service Features

Creating Folders for Messages

You can create up to ten folders to store your messages.
1. From the main menu, highlight **Messages** and press **OK**.
2. Highlight **Edit Folder** and press **OK**.
3. Highlight **Create Folder** and press **OK**.
4. Enter a keyword for the folder and press **OK**. (See “Entering Text” on page 25.) Incoming messages are automatically filtered into the folder if they contain the keyword you enter.
Note: You must enter a Keyword when creating a folder.
5. Enter a folder name and press **OK**.
6. Highlight the ringer type you want to have alert you when a message arrives in the folder and press **OK**. You will hear previews of the ringers as you highlight them.
Note: You can also create a folder from the Message Options page. (See “Message Options” on page 88.)

Editing Message Folders

To edit a folder:
1. From the main menu, highlight **Messages** and press **OK**.
2. Highlight **Edit Folder** and press **OK**.
3. Highlight the folder you wish to edit and press **OK**.
4. To select an option, highlight it and press **OK**.
_**Keyword** to change the folder’s keyword. Incoming messages are automatically filtered into the folder if they contain the Keyword you enter.
_**Folder Name** to change the folder’s name.
_**Ringer Type** to change the ringer type that alerts you when a new message arrives in the folder. You will hear previews of the ringers as you highlight them.
_**Erase Folder** to delete the folder and all its messages.
_**Exit** to return to the main menu.

Erasing All STi Mobile Messages

To erase all saved numeric pages:
1. From the main menu, highlight **Messages** and press **OK**.
2. Highlight **Erase All Msgs** and press **OK**.
3. A confirmation prompt will display. Highlight **Yes** and press **OK**.

Using Caller ID

Caller ID lets people know who's calling by displaying the number of the person calling. To block your phone number from being displayed for a specific outgoing call:

1. Press*Shift, **6**, **7**.
2. Enter the number you want to call.
3. Press **OK.**

Section 4 Safety Guidelines and Warranty Information

Section 4A Safety

In This Section

- **Getting the Most Out of Your Reception**
- **Maintaining Safe Use of and Access to Your Phone**
- **Caring for the Battery**
- **Acknowledging Special Precautions and the FCC Notice**
- **Consumer Information on Wireless Phones**

Part of getting the most out of your STi Mobile phone is learning how the phone works and how to care for it. This section outlines performance and safety guidelines that help you understand the basic features of your phone's operation.

Getting the Most Out of Your Reception

Keeping Tabs on Signal Strength

The quality of each call you make or receive depends on the signal strength in your area. Your phone informs you of the current signal strength by displaying a number of bars next to the signal strength icon. The more bars displayed, the stronger the signal. If you're inside a building, being near a window may give you better reception.

Understanding the Power Save Feature

If your phone is unable to find a signal after 15 minutes of searching, a Power Save feature is automatically activated. If your phone is active, it periodically rechecks service availability or you can check it yourself by pressing any key. Anytime the Power Save feature is activated, a message displays on the screen. When a signal is found, your phone returns to standby mode.

Understanding How Your Phone Operates

Your phone is basically a radio transmitter and receiver. When it's turned on, it receives and transmits radiofrequency (RF) signals. When you use your phone, the system handling your call controls the power level. This power can range from 0.006 watts to 0.2 watts in digital mode.

Knowing Radiofrequency Safety

The design of your STi Mobile phone complies with updated NCRP standards described below. In 1991-92, the Institute of Electrical and Electronics Engineers (IEEE) and the American National Standards Institute (ANSI) joined in updating ANSI's 1982 standard for safety levels with respect to human exposure to RF signals. More than 120 scientists, engineers and physicians from universities, government health agencies and industries developed this updated standard after reviewing the available body of research. In 1993, the Federal Communications Commission (FCC) adopted this updated standard in a regulation. In August 1996, the FCC adopted hybrid standard consisting of the existing ANSI/IEEE standard and the guidelines published by the
National Council of Radiation Protection and Measurements (NCRP).

Maintaining Your Phone's Peak Performance

There are several simple guidelines to operating your phone properly and maintaining safe, satisfactory service.

- Hold the phone with the antenna raised, fully-extended, and over your shoulder.
- Try not to hold, bend, or twist the phone's antenna.
- Don't use the phone if the antenna is damaged.
- Speak directly into the mouthpiece.

_Avoid exposing your phone and accessories to rain or liquid spills. If your phone does get wet, immediately turn the power off and remove the battery. If it's inoperable, call STi Mobile Customer Care for service.
Note: Faulty service may void the warranty.

Maintaining Safe Use of and Access to Your Phone

FAILURE TO FOLLOW THE INSTRUCTIONS OUTLINED MAY LEAD TO SERIOUS PERSONAL INJURY AND POSSIBLE PROPERTY DAMAGE

Using Your Phone While Driving

Talking on your phone while driving (or operating the phone without a hands-free device) is prohibited in some jurisdictions. Laws vary as to specific restrictions. Remember that safety always comes first.
When using your phone in the car:
_Get to know your phone and its features, such as speed dial and redial.
_When available, use a hands-free device.
_Position your phone within easy reach.
_Let the person you are speaking to know you are driving; if necessary; suspend the call in heavy traffic or hazardous weather conditions.
_Do not take notes or look up phone numbers while driving.
_Dial sensibly and assess the traffic; if possible, place calls when stationary or before pulling into traffic.
_Do not engage in stressful or emotional conversations that may divert your attention from the road.
_Dial 911 to report serious emergencies. It's free from your wireless phone.
_Use your phone to help others in emergencies.
_Call roadside assistance or a special non-emergency wireless number when necessary.
Tip: Purchase an optional hands-free car kit at your local STi Mobile Store. You may also call the STi Mobile Accessory Hotline at 1-800-974-2221 or by dialing on your STi Mobile phone.

Following Safety Guidelines

To operate your phone safely and efficiently, always follow any special regulations in a given area. Turn your phone off in areas where use is forbidden or when it may cause interference or danger.

Using Your Phone Near Other Electronic Devices

Most modern electronic equipment is shielded from radiofrequency (RF) signals. However, RF signals from wireless phones may affect inadequately shielded electronic equipment. RF signals may affect improperly installed or inadequately shielded electronic operating systems and/or entertainment systems in motor vehicles. Check with the manufacturer or their representative to determine if these systems are adequately shielded from external RF signals. Also check with the manufacturer regarding any equipment that has been added to your vehicle. Consult the manufacturer of any personal medical devices, such as pacemakers and hearing aids, to determine if they are adequately shielded from external RF signals.
Note: Always turn off the phone in health care facilities and request permission before using the phone near medical equipment.

Turning Off Your Phone Before Flying

Turn off your phone before boarding any aircraft. To prevent possible interference with aircraft systems, the U.S. Federal
Aviation Administration (FAA) regulations require you to have permission from a crew member to use your phone while the plane is on the ground. To prevent any risk of interference, FCC regulations prohibit using your phone while the plane is in the air.

Turning Off Your Phone in Dangerous Areas

To avoid interfering with blasting operations, turn off your phone when in a blasting area or in other areas with signs indicating that two-way radios should be turned off. Construction crews often use remote-control RF devices to set off explosives. Turn off your phone when you're in any area that has a potentially explosive atmosphere. Although it's rare, your phone or its accessories could generate sparks. Sparks could cause an explosion or a fire resulting in bodily injury or even death. These areas are often, but not always, clearly marked.
They include:
_Fueling areas such as gas stations.
_Below deck on boats.
_Fuel or chemical transfer or storage facilities.
_Areas where the air contains chemicals or particles such as grain, just or metal powders.
_Any other area where you would normally be advised to turn off your vehicle's engine.
Note: Never transport or store flammable gas, liquid or explosives in the compartment of your vehicle that contains your phone or accessories.

Restricting Children's Access to your Phone

Your STi Mobile phone is not a toy. Children should not be allowed to play with it because they could hurt themselves and others, damage the phone or make calls that increase your phone bill.

Caring for the Battery

Protecting Your Battery

The guidelines listed below help you get the most out of your battery's performance.

_Use only STi Mobile-approved batteries and desktop chargers. These chargers are designed to maximize battery life. Using other batteries or chargers voids your warranty and may cause damage.

_In order to avoid damage, charge the battery only in temperatures that range from 32º F to 113º F (0º C to 45º C).

_Don't use the battery charger in direct sunlight or in high humidity areas, such as the bathroom.

_Never dispose of the battery by incineration.

_Keep the metal contacts on top of the battery clean.

_Don't attempt to disassemble or short-circuit the battery.

_The battery may need recharging if it has not been used for a long period of time.

_It's best to replace the battery when it no longer provides acceptable performance. It can be recharged hundreds of times before it needs replacing.

_Don't store the battery in high temperature areas for long periods of time. It's best to follow these storage rules:

Less than one month:
4º F to 140º F (-20º C to 60º C)
More than one month:
4º F to 113º F (-20º C to 45º C)

Disposal of Lithium Ion (LiIon) Batteries

For safe disposal options of your LiIon batteries, contact your nearest STi Mobile-authorized service center.
Special Note: Be sure to dispose of your battery properly. In some areas, the disposal of batteries in household or business trash may be prohibited.
Note: For safety, do not handle a damaged or leaking LiIon battery.

Acknowledging Special Precautions and the FCC Notice

FCC Notice

The phone may cause TV or radio interference if used in close proximity to receiving equipment. The FCC can require you to stop using the phone if such interference cannot be eliminated. Vehicles using liquefied petroleum gas (such as propane or butane) must comply with the National Fire Protection Standard (NFPA-58). For a copy of this standard, contact the National Fire Protection Association, One Batterymarch Park, Quincy, MA 02269, Attn: Publication Sales Division.

Cautions

Any changes or modifications to your phone not expressly approved in this document could void your warranty for this equipment, and void your authority to operate this equipment. Only use approved batteries, antennas and chargers. The use of any unauthorized accessories may be dangerous and void the phone warranty if said accessories cause damage or a defect to the phone. Although your phone is quite sturdy, it is a complex piece of equipment and can be broken. Avoid dropping, hitting, bending or sitting on it.

Body-Worn Operation

To maintain compliance with FCC RF exposure guidelines, if you wear a handset on your body, use the STi Mobile supplied or approved carrying case, holster or other body-worn accessory. If you do not use a body-worn accessory, ensure that the antenna is at least 7/16 inch (1.5 centimeters) from your body when transmitting. Use of non-STi Mobile approved accessories may violate FCC RF exposure guidelines. For more information about RF exposure, please visit the FCC Web site at www.fcc.gov.

Specific Absorption Rates (SAR) for Wireless Phones

The SAR is a value that corresponds to the relative amount of RF energy absorbed in the head of a user of a wireless handset. The SAR value of a phone is the result of an extensive testing, measuring and calculation process. It does not represent how much RF the phone emits. All phone models are tested at their highest value in strict laboratory settings. But when in operation, the SAR of a phone can be substantially less than the level reported to the FCC. This is because of a variety of factors including its proximity to a base station antenna, phone design and other factors. What is important to remember is that each phone meets strict federal guidelines. Variations in SARs do not represent a variation in safety. All phones must meet the federal standard, which incorporates a substantial margin

of safety. As stated above, variations in SAR values between different model phones do not mean variations in safety. SAR values at or below the federal standard of 1.6 W/kg are considered safe for use by the public.
The highest reported SAR values of the 1200 are: PCS mode (Part 24E) - Head: 0.830 W/kg; Body-worn: 0.304 W/kg

FCC Radiofrequency Emission

This phone meets the FCC Radiofrequency Emission Guidelines. FCC ID number: **BEJLX1200**. More information on the phone's SAR can be found from the following FCC Web site: http://www.fcc.gov/oet/fccid.

Owner's Record

The model number, regulatory number and serial number are located on a nameplate inside the battery compartment. Record the serial number in the space provided below. This will be helpful if you need to contact us about your phone in the future.
Model: STi Mobile Phone by LG® (1200)
Serial No.:

User Guide Proprietary Notice

CDMA Technology is licensed by QUALCOMM Incorporated under one or more of the following patents:
4,901,307 5,109,390 5,267,262 5,416,797
5,506,865 5,544,196 5,657,420 5,101,501
5,267,261 5,414,796 5,504,773 5,535,239
5,600,754 5,778,338 5,228,054 5,337,338
5,710,784 5,056,109 5,568,483 5,659,569
5,490,165 5,511,073
T9 Text Input is licensed by Tegic Communications and is
covered by U.S. Pat. 5,818,437, U.S. Pat. 5,953,541, U.S. Pat. 6,011,554 and other patents pending.

Section 4B Manufacturer's Warranty

_ Manufacturer's Warranty

This section contains the manufacturer's warranty for your STi Mobile phone. For information about the Terms and Conditions of your STi Mobile service, please see the User Tips foldout included with your phone. For the most recent version of the Terms and Conditions, please visit www.stimobile.com.

Customer Limited Warranty

STi Mobile offers you a limited warranty that the enclosed subscriber unit (Product), including accessories in the product package, will be free from defects in material or workmanship as follows:
1. SUBSCRIBER UNIT
A. STi Mobile ONE (1) YEAR LIMITED WARRANTY. For a period of one (1) year from the date of purchase, STi Mobile will, at its option, either pay the parts and labor charges to any authorized STi Mobile phone service facility to repair or replace a defective Product (with new or rebuilt parts/replacements). After this one (1) year period, you must pay all parts, shipping and labor charges.
B. REPAIRS: For a period equal to the remainder of the original limited warranty period on an original Product or for the 180 days after the date of repair/replacement, whichever is longer, STi Mobile will repair or replace (with new or rebuilt replacements) defective parts or Product used in the repair or replacement of the original Product under this Limited Warranty.
Proof of purchase in the form of a bill of sale or receipted invoice or warranty repair document which is evidence that the Product is within the warranty period must be presented to obtain warranty service. This limited warranty is not transferable to any third party, including but not limited to any subsequent purchaser or owner of the Products. Transfer or resale of a Product will automatically terminate warranty coverage with respect to the Products. This limited warranty does not cover and is void with respect to the following: (i) Products which have been improperly installed, repaired, maintained or modified (including the antenna); (ii) Products which have been subjected to misuse (including Products used in conjunction with hardware electrically or mechanically incompatible or used with accessories not supplied by STi Mobile), abuse, accident, physical damage, abnormal operation, improper handling and storage, neglect, exposure to fire, water or excessive moisture or dampness or extreme changes in climate or temperature; (iii) Products operated outside published maximum ratings; (iv) cosmetic damage; (v) Products on which warranty stickers or Product serial numbers have been removed, altered, or rendered illegible; (vi) customer instruction: (vii) cost of installation, removal or reinstallation; (viii) signal reception problems (unless caused by defect

in material and workmanship): (ix) damage the result of fire, flood, acts of God or other acts which are not to the fault of STi Mobile and which the Product is not specified to tolerate, including damage caused by mishandling and blown fuses; (x) consumables (such as fuses); or (xi) any Products which have been opened, repaired, modified or altered by anyone other than STi Mobile or a STi Mobile Authorized Service Center.
This warranty does not cover customer education, instruction, installation, set up adjustments, or signal reception problems.
This warranty is valid only in the United States.
USE WITH ACCESSORIES NOT SUPPLIED BY SPRINT OR OTHERWISE NOT EXPRESSLY AUTHORIZED BY SPRINT MAY BE DANGEROUS. STi Mobile SPECIFICALLY DISCLAIMS LIABILITY, AND SHALL HAVE NO OBLIGATION TO PROVIDE TO BUYER ANY OTHER REMEDY, FOR ANY AND ALL DIRECT, INDIRECT, SPECIAL,
GENERAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING, BUT NOT LIMITED TO LOSS OF PROFITS, LOSS OF SALES, LOSS OF USE OF THE PRODUCT, OR ANTICIPATED PROFITS ARISING OUT OF USE OF OR INABILITY TO USE ANY PRODUCT (FOR EXAMPLE, WASTED AIRTIME CHARGES DUE TO THE MALFUNCTION OF A PRODUCT), DAMAGE DUE TO IMPROPER OPERATION OR MAINTENANCE, INSTALLATION, CONNECTION TO IMPROPER VOLTAGE SUPPLY, OR ATTEMPTED REPAIR OF THE PRODUCT BY ANYONE OTHER THAN A FACILITY AUTHORIZED BY STi Mobile. THIS WARRANTY DOES NOT COVER PRODUCTS SOLD AS IS OR WITH ALL FAULTS, OR CONSUMABLES, (SUCH AS FUSES). THIS WARRANTY DOES NOT APPLY WHEN THE MALFUNCTION RESULTS FROM USE OF THE PRODUCT IN CONJUNCTION WITH ACCESSORIES, PRODUCTS OR ANCILLARY OR PERIPHERAL EQUIPMENT NOT SUPPLIED BY OR EXPRESSLY
AUTHORIZED FOR USE BY STi Mobile, AND WHERE IT IS DETERMINED BY STi Mobile THAT THERE IS NO FAULT WITH THE PRODUCT ITSELF. REPAIR OR REPLACEMENT, AS PROVIDED BY THE WARRANTY, IS YOUR SOLE AND EXCLUSIVE REMEDY FOR BREACH OF THE LIMITED WARRANTY. TO THE EXTENT PERMITTED BY APPLICABLE LAW, STi Mobile MAKES NO OTHER WARRANTIES OF ANY KIND, EXPRESS OR IMPLIED, WITH
RESPECT TO THE PRODUCTS FOR A PARTICULAR PURPOSE OR AGAINST INFRINGEMENT WITHIN THE TIME PERIOD SPECIFIED IN THE LIMITED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR
PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.
Some States do not allow the exclusion or limitation of incidental or consequential damages, or allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This limited warranty gives you specific legal rights, and you may also have other rights which vary from state to state. For other Warranty Service Information, please call STi Mobile CUSTOMER CARE at 1-800-784-3277.

Index

A
AC Adapter Charger 16
Answering Calls 18
Anykey Answer 36
Auto-Answer Mode 37
B
Backlight 33
Battery
Capacity 15
Charging 16
Disposal 106
Installing 15
Removing 15
C
Calculator 72
Call Guard 46
Call History
Erasing 55
Making a Call From 53
Options 52
Saving a Phone Number
From 54
Viewing 52
Caller ID 91
Customer Care 6

D
Dialing Options 19
Directory Assistance 6
Display Screen Symbols 12
Display Settings 33–35
E
Entering Text
ABC Mode 27
Selecting a Character Input Mode 25
Symbols, Numbers, and Smileys 27
T9 Text Input 26
F
FCC Notice 107
G
Games 73
Getting Started With STi Mobile Service 4
Greeting 33
I
Internal Phone Book
Adding an Entry 60
Calling a Number From 24
Editing Entries 61
Erasing 41
Options 59
Secret Entries 63
L
Location Settings 36
Locking Your Phone 40
M
Making Calls 17
Manufacturer's Warranty 112
Menus
Diagram 49
Navigation 48
Structure 48
Viewing 49
Missed Call Notification 18
118 Index
N
Navigating Menus 48
P
STi Mobile Messages 86–91
Erasing 91
Folders 90
Options 88
STi Mobile Services
Customer Service Care 6
Directory Assistance 6
Operator Services 6
Phone Number
Displaying 17
Phone Numbers
Finding 23
Saving 22
With Pauses 23
R
Resetting Your Phone 42
Ringer Types 31
S

Scheduler 66
Screen Saver 35
Security Menu 40
Setting Up Your Voicemail 5
Silent Mode 32
Special Numbers 41
Speed Dialing 25
T
T9 Text Input 26
Tone Length 30
TTY Use 37
Turning Your Phone On and Off 14